



## ACM-2353 SETUP GUIDE


Using either the CD that comes with your equipment or if you downloaded an installation file from our website please note, that this is correct procedure to install and use the AKTAKOM ACM-2056 or ACM-2353 clamp meter application software.

1. Setting up the Driver in your PC. Please do not connect the USB device yet.

The driver will allow your computer to recognize the USB or USB wireless device so you can communicate in both directions using the AKTAKOM application software.



AKTAKOM ACM-2056 or ACM-2353 driver installs:

Double click the CP210x\_VCP\_Win\_XP\_S2K3\_Vista\_7.exe driver file.





Now click to run the driver in to your computer then NEXT and please agree with the end user license agreement.


## ACM-2353 SETUP GUIDE




## ACM-2353 SETUP GUIDE



## ACM-2353 SETUP GUIDE




- **At this moment**, you must connect the USB device so the driver software can find the USB communication port.





## ACM-2353 SETUP GUIDE

2. Installing AKTAKOM ACM-2353 application software (as administrator only):



Please double click to start setup




This is a transition screen for you to know that you are installing the AKTAKOM ACM-2353

## ACM-2353 SETUP GUIDE




This will install the ACM-2353 Software application








## ACM-2353 SETUP GUIDE



**Please note:** If you are using an old Microsoft Windows versions the application may not work with your Microsoft Windows version. If you decide to install anyway the driver installation software will not allow you to install over the newer driver version.




## ACM-2353 SETUP GUIDE



3. Launching your application software application so then will appear on your screen the equipment. (There may be different color and model number).

## ACM-2353 SETUP GUIDE



You may see the complete software application menu in your Windows all programs start button. Also a quick hyperlink icon will appear in your menu bar and desktop. Please fill free to start the application from any of them.





## ACM-2353 SETUP GUIDE




Be aware that USB function turn off the Auto Power function that may cause you to lose your battery at all. If you do not turn on the Wireless USB function, the meter will auto off after 30 minutes.

As soon as you connect the USB device data appears on the screen of your virtual equipment in your computer.





## ACM-2353 SETUP GUIDE



Graph screen shall print in default printer only.

From now on you will be able to read measurements from your equipment up to 330 ft at an unobstructed field.

Just press Exit to close the application software and do not forget to turn off the equipment to save battery.